

CANON RS-80 N3 CABLE RELEASE

Varenummer: CAND0085



360.00

DKK ex moms

450.00

DKK incl moms

Produkteksperter:



Lars Thstrup
lars@goecker.dk
35865106
København



Kenneth Lauritzen
lars@goecker.dk
35865126
København

Beskrivelse:

Canon RS-80N3 Remote Switch

An 80 cm remote release for EOS cameras featuring an N3-type socket. Two-stage control button behaves in the same way as your camera's shutter release, activating AF on a half-press. The switch also features a lock allowing you to lock the shutter button down for long exposure times or unattended continuous shooting.

Compatibility

- EOS-1D X Mark II
- EOS 5DS
- EOS 5DS R
- EOS 5D Mark IV
- EOS 6D
- EOS 6D Mark II
- EOS 7D II
- EOS-1D X
- EOS-1D C
- EOS-1Ds Mark III
- EOS-1Ds Mark II
- EOS-1Ds
- EOS-1D Mark IV
- EOS-1D Mark III
- EOS-1D Mark II
- EOS-1D
- EOS 5D Mark III
- EOS 5D Mark II
- EOS 5D
- EOS 20D
- EOS 7D
- EOS 50D
- EOS 40D
- EOS 30D
- EOS-1D X Mark III
- EOS R5
- EOS R3

Specifikationer:

Producent	Canon
Kategori	Fjernbetjening
Leverandør	Canon