

DJI OSMO POCKET ACCESSORY MOUNT PART 3 //

Varenummer: DJI480294



88.00

DKK ex moms

110.00

DKK incl moms



Produkteksperter:



Ronni Jaqué
ronni@goecker.dk
35865107
København



Morten H. Vorsaa
ronni@goecker.dk
35865141
Aarhus

Kampagne:

Lagersalg

Denne vare er nu nedsat.

Tilbuddet gælder kun så længe lager haves.

[Se hele vores lagersalg her >>](#)

Beskrivelse:

The DJI Osmo Pocket Accessory Mount provides a two-prong mount for attaching three-prong accessories on the front of the Osmo Pocket Gimbal. It clasps on around the center of the gimbal.

Specifikationer:

Producent	DJI
Kategori	Diverse
Leverandør	Boston