

PROFOTO GRID 20 GR. T/ D1/D2 FLASH

Varenummer: PROF100797



692.00

DKK ex moms



865.00

DKK incl moms

Produkteksperter:



Lars Thestrup

lars@goecker.dk

35865106

København



Jakob Worre

jakob@goecker.dk

35865142

Aarhus

Beskrivelse:

Limit the light spread.

Grids are uncomplicated accessories that limit the light spread. Use them to shape your key light, create background effects in portraits, or accentuate highlights in still life photography. All these Grids are mounted directly onto your D1 monolight.

- Easy to use.
- Integrated clips for heat resistant filters and gels.
- Available in 5°, 10° and 20° light spread versions.

Goecker for shooters

Specifikationer:

Producent	Profoto
Kategori	Flash skærme
Leverandør	Profoto